


AUTO LIGHT SYSTEM WIRING DIAGRAM

B3E091801052T14



B3E09 18T002

1	Auto light sensor
2	Light switch
3	Microcomputer
4	Headlight LO relay
5	Headlight HI relay
6	TNS relay
7	Headlight (low-beam)
8	Headlight (high-beam)
9	To illumination light