


MAP LIGHT INSPECTION

B3E091801058W02

1. Verify that the continuity between the map light terminals is as indicated in the table.



- If not as indicated in the table, replace the map light.

Switch position		Terminal		
Map light switch	Interior light switch	B	C	D
On	-		○ — ○ — ○ — ○	
-	DOOR	○ — ○ — ○		
Off	OFF			

B3E0918WA14