


ROOM LIGHT CONTROL SYSTEM FUNCTION

B3E091851311T02

- The interior light control system turns on, turns off, or dims the interior light when the interior light switch is in the DOOR position.



B3E0918T118

1	Key reminder switch
2	Map light
3	Interior light
4	Ignition key illumination
5	Door
6	On
7	Front door latch switch (LH)
8	Rear door latch switch (LH)
9	Front door latch switch (RH)
10	Rear door latch switch (RH)
11	Lock
12	Unlock
13	Door lock-link switch