

IGNITION KEY ILLUMINATION OPERATION

B3E091851311T05

Illumination Condition

- The ignition key illumination glows under all of the following conditions:

- Driver-side door is open. (Driver-side latch switch is on.)
- Ignition switch is at the LOCK or ACC position. (IG1 off)

Cancel Condition

- The ignition key illumination goes out under any of the following conditions:

- **Approx. 30 s** after all doors are closed. (**Approx. 30 s** after all latch switches are off.)
- Ignition switch is at the ON position. (IG1 on)
- **Approx. 5 min** after ignition key illumination begins.