


# HAZARD WARNING SWITCH INSPECTION

B3E091866401W02

1. Verify that the continuity between the hazard switch terminals is as indicated in the table.



- If not as indicated in the table, replace the hazard warning switch.

Switch position	Terminal			
	A	C	E	F
Off			○—○	○—○
On	○—○		○—○	○—○

○—○ : Continuity ○—○ : Bulb

B3E0918W133