


FRONT AND REAR FOG LIGHT SWITCH INSPECTION

B3E091866402W01

1. Verify that the continuity between the front and rear fog light switch terminals is as indicated in the table.



- If not as indicated in the table, replace the light switch.

Switch position			Terminal		
Light	Front fog light switch	Rear fog light switch	E	H	I
OFF	OFF	—			
	ON	—	○—○		
	ON	ON	○—○—○		
TNS	ON	OFF	○—○		
	ON	ON	○—○—○		
Head light	ON	OFF	○—○		
	ON	ON	○—○—○		
Auto	ON	OFF	○—○		
	ON	ON	○—○—○		

○—○ : Continuity

B3E0918W 131