

# WINDSHIELD WIPER ARM AND BLADE ADJUSTMENT

---

B3E091967320W02

1. Operate the windshield wipers, and turn off the windshield wiper motor to set the wipers in the park position.
2. Adjust the windshield wiper arm connector shafts to set the arm heights as shown.

