


WASHER FLUID-LEVEL SENSOR FUNCTION


B3E091967488T01

- Warns the driver that the washer fluid-level is low.



B3E0919T110

1	Washer fluid-level indicator light
2	Instrument cluster



B3E0919T117

1	Instrument cluster
2	Microcomputer
3	Washer fluid-level indicator light
4	Washer fluid-level sensor