


CENTER PANEL MODULE DISASSEMBLY/ASSEMBLY

B3E092066900W03

Caution

- Before disassembling the center panel module, spread a cloth on the floor to put the disassembled parts on. This protects the surface of the panel from scratches or dirt.

1. Disassemble in the order indicated in the table.
2. Assemble in the reverse order of disassembly.



B3E09201W006

1	Screw A
2	Information display
3	Screw B
4	Audio unit
5	Center panel
6	Cover (upper module) (See Cover Removal Note.)
7	Cover (lower module) (See Cover Removal Note.)

Cover Removal Note

1. Pull the cover (upper or lower module) outward, detach clip A from the center panel, and then remove the cover.

