


AUDIO UNIT DISASSEMBLY/ASSEMBLY

B3E092066900W04

1. Disassemble in the order indicated in the table.



1	Screw
2	Cover (vehicles without the upper module)
3	Upper module
4	Screw
5	Lower module
6	Base unit

2. Assemble in the reverse order of disassembly.