


CAR-NAVIGATION UNIT REMOVAL/INSTALLATION

B3E092066902W01

1. Disconnect the negative battery cable.
2. Remove the decoration panel.(See [DECORATION PANEL REMOVAL/INSTALLATION.](#))
3. Remove the front scuff plate.(See [FRONT SCUFF PLATE REMOVAL/INSTALLATION.](#))
4. Remove the front side trim.(See [FRONT SIDE TRIM REMOVAL/INSTALLATION.](#))
5. Remove the glove compartment.(See [GLOVE COMPARTMENT REMOVAL/INSTALLATION.](#))
6. Remove in the order indicated in the table.



1	Nut
2	Connector
3	Car-navigation unit

7. Install in the reverse order of removal.