


# CAR-NAVIGATION CONTROL SWITCH CONSTRUCTION/OPERATION

B3E092066921T02


## Construction

- The car-navigation control switch is located on the console.



1	Car-navigation control switch
---	-------------------------------

## Terminal layout and signal

Terminal	Signal
	A -
	B -
	C -
	D -
	E -
	F -
	G B+
	H Ground
	I Illumination (+)
	J -
	K Remote-data
	L Shield ground
	M -
	N -
	O -
	P -

## Operation

No.	Button (component)	Function
1	[POS (Position)] button	Displays the current position.
2	Joystick	Selects items by tilting it up, down, right and left.
3	[ENTER] button	Executes a selected item.
4	[RET] button	Returns to the previous screen.
5	[MENU] button	Selects menus.
6	[ZOOM] button	Changes the map scale.
7	[VOICE] button	Initiates vocal guidance for route maneuvers.
8	[DIM] button	Cancel the night mode.