

CIGARETTE LIGHTER INSPECTION

B3E092067000W02

1. Turn the ignition switch to the ACC position.
2. Press the cigarette lighter into the socket and verify that it returns to its original position in **10-20 s**.
 - If the cigarette lighter does not operate normally, replace the cigarette lighter and the socket.