


RELAY LOCATION

B3E092167730W01



B3E0921W010

1	Main relay
2	Starter relay
3	A/C relay
4	Horn relay
5	Blower relay
6	Rear window defroster relay
7	Front fog light relay
8	Headlight cleaner relay
9	Fuel pump relay
10	Running light relay