


TURN AND HAZARD INDICATOR ALARM CONSTRUCTION/OPERATION

B3E092255430T10

System Wiring Diagram



1	Instrument cluster
2	Microcomputer
3	Indicator buzzer
4	CAN control circuit
5	AND

Operation

- The turn and hazard signal sent from the PJB via the CAN system is input to the microcomputer in the instrument cluster. The microcomputer sends an output signal to the turn indicator light and the indicator buzzer.