


# INSTRUMENT CLUSTER DISASSEMBLY/ASSEMBLY

B3E092255430W03

## Caution

- Do not drop the instrument cluster or damage the printed board. This will lead to a system malfunction.

1. Disassemble in the order indicated in the table.



1	Screw
2	Cover
3	Instrument cluster unit
4	Hood
5	Lens

2. Assemble in the reverse order of disassembly.