


TORQUE BOX REMOVAL

B3E098053381B01

1. Remove the torque box.



B3E0980B070