

## REAR FENDER RAIN RAIL AND CORNER PLATE REMOVAL


B3E098070440B01

### 4SD

1. Remove the rear fender rain rail and corner plate.

#### Note

- When removing the rear fender rain rail and the corner plate separately, drill the 3 locations indicated by (A).



B3E0980B098

### 5HB

1. Remove the rear fender rain rail and corner plate.

### Note

- When removing the rear fender rain rail and the corner plate separately, drill the 8 locations indicated by (A).

