

- [!\[\]\(1207edb9a08751d3d55970560645ed23_img.jpg\) SYSTEM WIRING DIAGRAM](#)
- [!\[\]\(d7a34a706cfa4ef37c62a369101e1b36_img.jpg\) FOREWORD](#)
- [!\[\]\(7325769475e8f4bf67f57a0cbebc8ab9_img.jpg\) PRECAUTION](#)
- [!\[\]\(1a468f12cdfc63dc07896d0781cf55ec_img.jpg\) SYMPTOM TROUBLESHOOTING](#)
- [!\[\]\(a9a0baec8ceb7d7c04180806eca8d32a_img.jpg\) NO.1 NEITHER ABS WARNING LIGHT NOR BRAKE SYSTEM WARNING LIGHT ILLUMINATE WHEN THE IGNITION SWITCH IS TURNED TO THE ON POSITION](#)
- [!\[\]\(c1ab807d6aebb565b3082513037b5622_img.jpg\) NO.2 ABS WARNING LIGHT DOES NOT ILLUMINATE WHEN THE IGNITION SWITCH IS TURNED TO THE ON POSITION](#)
- [!\[\]\(083bb479299cb5e55cd99db0433ca6ba_img.jpg\) NO.3 BRAKE SYSTEM WARNING LIGHT DOES NOT ILLUMINATE WHEN THE IGNITION SWITCH IS TURNED TO THE ON POSITION](#)
- [!\[\]\(ede41f318336daae6cce8449321d11ea_img.jpg\) NO.4 BOTH ABS WARNING LIGHT AND BRAKE SYSTEM WARNING LIGHT STAY ON 4 S OR MORE WHEN THE IGNITION SWITCH IS TURNED TO THE ON POSITION](#)
- [!\[\]\(b0cd9d88e5935e4c3891570bfdded05c_img.jpg\) NO.5 ABS WARNING LIGHT STAYS ON 4 S OR MORE WHEN THE IGNITION SWITCH IS TURNED TO THE ON POSITION](#)
- [!\[\]\(81bb4e52f43acc06353225c332f66031_img.jpg\) NO.6 BRAKE SYSTEM WARNING LIGHT STAYS ON 4 S OR MORE WHEN THE IGNITION SWITCH IS TURNED TO THE ON POSITION \(PARKING BRAKE IS RELEASED\)](#)
- [!\[\]\(4862a3d83a50b6aa02d9ef677ec36116_img.jpg\) NO.7 THERE IS MALFUNCTION IN THE SYSTEM EVEN THOUGH ABS WARNING LIGHT, BRAKE SYSTEM WARNING LIGHT, DO NOT ILLUMINATE](#)
- [!\[\]\(b564abb3972f4216a833af91832e1619_img.jpg\) NO.8 ANY OF THE FOLLOWING LIGHTS DO NOT ILLUMINATE WHEN THE IGNITION SWITCH IS TURNED TO THE ON POSITION: \(ABS WARNING LIGHT, BRAKE SYSTEM WARNING LIGHT, DSC INDICATOR LIGHT AND/OR DSC OFF LIGHT\)](#)
- [!\[\]\(3e91863309aa91e589b5ab92c8ebd53f_img.jpg\) NO.9 ANY OF THE FOLLOWING LIGHTS REMAIN ON: \(ABS WARNING LIGHT, BRAKE SYSTEM WARNING LIGHT, DSC INDICATOR LIGHT AND/OR DSC OFF LIGHT\)](#)
- [!\[\]\(bf6def3f21dfdb4b0473718404626f2c_img.jpg\) NO.10 THERE IS A MALFUNCTION IN THE SYSTEM EVEN THOUGH ABS WARNING LIGHT, BRAKE SYSTEM WARNING LIGHT, DSC INDICATOR LIGHT AND DSC OFF LIGHT DO NOT ILLUMINATE](#)
- [!\[\]\(b0485233f98b941f2381b77fe3b6686f_img.jpg\) NO.11 ABS OR TCS*1 OPERATES FREQUENTLY/TCS DOES NOT WORK CORRECTLY *1: DSC SYSTEM FUNCTION CONTAINS TRACTION CONTROL FUNCTION, DSC INDICATOR LIGHT GOES ON AND OUT WHILE DSC OPERATES](#)
- [!\[\]\(fd5c36680d4471e605732b36788643ca_img.jpg\) NO.12 DSC*2 OPERATES FREQUENTLY/DSC DOES NOT WORK CORRECTLY *2: DSC INDICATOR LIGHT GOES ON AND OUT WHILE DSC OPERATES](#)