

- [!\[\]\(1207edb9a08751d3d55970560645ed23_img.jpg\) SECURITY AND LOCKS LOCATION INDEX](#)
- [!\[\]\(d7a34a706cfa4ef37c62a369101e1b36_img.jpg\) FRONT OUTER HANDLE REMOVAL/INSTALLATION](#)
- [!\[\]\(7325769475e8f4bf67f57a0cbebc8ab9_img.jpg\) REAR OUTER HANDLE REMOVAL/INSTALLATION](#)
- [!\[\]\(1a468f12cdfc63dc07896d0781cf55ec_img.jpg\) INNER HANDLE REMOVAL/INSTALLATION](#)
- [!\[\]\(a9a0baec8ceb7d7c04180806eca8d32a_img.jpg\) FRONT DOOR KEY CYLINDER REMOVAL/INSTALLATION](#)
- [!\[\]\(c1ab807d6aebb565b3082513037b5622_img.jpg\) FRONT DOOR LATCH AND LOCK ACTUATOR REMOVAL/INSTALLATION](#)
- [!\[\]\(083bb479299cb5e55cd99db0433ca6ba_img.jpg\) REAR DOOR LATCH AND LOCK ACTUATOR REMOVAL/INSTALLATION](#)
- [!\[\]\(ede41f318336daae6cce8449321d11ea_img.jpg\) FRONT DOOR LATCH AND LOCK ACTUATOR INSPECTION](#)
- [!\[\]\(b0cd9d88e5935e4c3891570bfdded05c_img.jpg\) REAR DOOR LATCH AND LOCK ACTUATOR INSPECTION](#)
- [!\[\]\(81bb4e52f43acc06353225c332f66031_img.jpg\) FRONT DOOR LOCK ACTUATOR INSPECTION](#)
- [!\[\]\(4862a3d83a50b6aa02d9ef677ec36116_img.jpg\) REAR DOOR LOCK ACTUATOR INSPECTION](#)
- [!\[\]\(b564abb3972f4216a833af91832e1619_img.jpg\) FRONT DOOR LATCH SWITCH INSPECTION](#)
- [!\[\]\(3e91863309aa91e589b5ab92c8ebd53f_img.jpg\) REAR DOOR LATCH SWITCH INSPECTION](#)
- [!\[\]\(bf6def3f21dfdb4b0473718404626f2c_img.jpg\) DOOR LOCK-LINK SWITCH INSPECTION](#)
- [!\[\]\(b0485233f98b941f2381b77fe3b6686f_img.jpg\) FRONT DOOR KEY CYLINDER SWITCH INSPECTION](#)
- [!\[\]\(fd5c36680d4471e605732b36788643ca_img.jpg\) DOOR LOCK STRIKER REMOVAL/INSTALLATION](#)
- [!\[\]\(cfcb6e3fe14cf2366208370376c5c0f9_img.jpg\) FUEL-FILLER LID OPENER REMOVAL/INSTALLATION \[L.H.D.\]](#)
- [!\[\]\(17fbea93b96fb691279feb16b3dfba47_img.jpg\) FUEL-FILLER LID OPENER REMOVAL/INSTALLATION \[R.H.D.\]](#)
- [!\[\]\(c943c40aac9d4dd9481d8d4b932db11b_img.jpg\) BONNET LATCH AND RELEASE LEVER REMOVAL/INSTALLATION \[L.H.D.\]](#)
- [!\[\]\(78722dd8a40b4b8cba6c4bc2496af0ff_img.jpg\) BONNET LATCH AND RELEASE LEVER REMOVAL/INSTALLATION \[R.H.D.\]](#)
- [!\[\]\(7ca57550f01dd657cd5fb0b4b39070e5_img.jpg\) BONNET LATCH SWITCH INSPECTION](#)
- [!\[\]\(27d08d42762e05345080235dfb8fd4f5_img.jpg\) KEYLESS CONTROL MODULE REMOVAL/INSTALLATION](#)
- [!\[\]\(a0120eed5345e3ef041f32d510bbaaa4_img.jpg\) KEYLESS CONTROL MODULE INSPECTION](#)
- [!\[\]\(5d135eaf0db5ba5bb50522e31d409887_img.jpg\) TRANSMITTER BATTERY REPLACEMENT](#)
- [!\[\]\(999a3b623d1b2e259ce371a576a89b57_img.jpg\) TRANSMITTER BATTERY INSPECTION](#)
- [!\[\]\(b6fcbc36e74bb8f6df2b3fdc5d230a1a_img.jpg\) TRANSMITTER ID CODE REGISTRATION](#)
- [!\[\]\(32a22410411096e2c8d32731f78c9ccc_img.jpg\) TRUNK LID LATCH AND OPENER REMOVAL/INSTALLATION](#)
- [!\[\]\(c0c9b82c73e1cc6d7e87bf54578e2a82_img.jpg\) TRUNK LID OPENER INSPECTION](#)
- [!\[\]\(3a6ac41b3f099dd17a52d14a1994c5e3_img.jpg\) TRUNK LID LATCH SWITCH INSPECTION](#)
- [!\[\]\(d8728fc7d0d18b43bb799e0b75e28476_img.jpg\) TRUNK LID KEY CYLINDER REMOVAL/INSTALLATION](#)
- [!\[\]\(70bb55f7aa836a2ee4c67662da4967eb_img.jpg\) TRUNK LID KEY CYLINDER SWITCH INSPECTION](#)
- [!\[\]\(b2232297cce97c56f57b421760817d12_img.jpg\) TRUNK LID KEY CYLINDER PUSH SWITCH INSPECTION](#)
- [!\[\]\(55709881e7481dfc15adc40dcd59becf_img.jpg\) TRUNK LID LOCK STRIKER REMOVAL/INSTALLATION](#)
- [!\[\]\(8d83d449d7624cdb4d2f61b11873010a_img.jpg\) LIFTGATE OUTER HANDLE REMOVAL/INSTALLATION](#)
- [!\[\]\(08e72e8a418b20d39ee1ac7f725378d8_img.jpg\) LIFTGATE LATCH AND LOCK ACTUATOR REMOVAL/INSTALLATION](#)
- [!\[\]\(1472b7e8436c1b3bc5eeea25b271593e_img.jpg\) LIFTGATE LOCK ACTUATOR INSPECTION](#)
- [!\[\]\(57e556a88107516655813e6c23d2abae_img.jpg\) LIFTGATE LATCH SWITCH INSPECTION](#)
- [!\[\]\(c030b7e6eb2494eaedb757293e6adf2c_img.jpg\) LIFTGATE KEY CYLINDER REMOVAL/INSTALLATION](#)
- [!\[\]\(5bad85d70f3eb6f5fbcfc80073eb6615_img.jpg\) LIFTGATE LOCK STRIKER REMOVAL/INSTALLATION](#)
- [!\[\]\(1809a30bd9cc86d1611d658a2943747d_img.jpg\) INTRUDER SENSOR REMOVAL/INSTALLATION](#)
- [!\[\]\(ebce444f4bff1003b265f30c0e6b85ba_img.jpg\) THEFT-DETERRENT SIREN REMOVAL/INSTALLATION \[4SD\]](#)
- [!\[\]\(8e0f7d31a6b42179701b60b1a6e779d2_img.jpg\) THEFT-DETERRENT SIREN REMOVAL/INSTALLATION \[5HB\]](#)
- [!\[\]\(9a27f7f6603fb7c664d1a82b91188a1b_img.jpg\) COIL ANTENNA REMOVAL/INSTALLATION](#)
- [!\[\]\(1b742e4ee6400795e0df67c7dfb0086a_img.jpg\) IMMOBILIZER SYSTEM COMPONENT REPLACEMENT/KEY ADDITION AND CLEARING](#)