

- [!\[\]\(1207edb9a08751d3d55970560645ed23_img.jpg\) INTAKE-AIR SYSTEM OUTLINE \[LF\]](#)
- [!\[\]\(d7a34a706cfa4ef37c62a369101e1b36_img.jpg\) INTAKE-AIR SYSTEM STRUCTURAL VIEW \[LF\]](#)
- [!\[\]\(7325769475e8f4bf67f57a0cbebc8ab9_img.jpg\) INTAKE-AIR SYSTEM DIAGRAM \[LF\]](#)
- [!\[\]\(1a468f12cdfc63dc07896d0781cf55ec_img.jpg\) INTAKE-AIR SYSTEM HOSE ROUTING DIAGRAM \[LF\]](#)
- [!\[\]\(a9a0baec8ceb7d7c04180806eca8d32a_img.jpg\) RESONANCE CHAMBER FUNCTION \[LF\]](#)
- [!\[\]\(c1ab807d6aebb565b3082513037b5622_img.jpg\) AIR CLEANER CONSTRUCTION \[LF\]](#)
- [!\[\]\(083bb479299cb5e55cd99db0433ca6ba_img.jpg\) THROTTLE BODY CONSTRUCTION \[LF\]](#)
- [!\[\]\(ede41f318336daae6cce8449321d11ea_img.jpg\) IDLE AIR CONTROL \(IAC\) VALVE FUNCTION \[LF\]](#)
- [!\[\]\(b0cd9d88e5935e4c3891570bfdded05c_img.jpg\) IDLE AIR CONTROL \(IAC\) VALVE CONSTRUCTION/OPERATION \[LF\]](#)
- [!\[\]\(81bb4e52f43acc06353225c332f66031_img.jpg\) INTAKE MANIFOLD CONSTRUCTION \[LF\]](#)
- [!\[\]\(4862a3d83a50b6aa02d9ef677ec36116_img.jpg\) VARIABLE INTAKE-AIR SYSTEM FUNCTION \[LF\]](#)
- [!\[\]\(b564abb3972f4216a833af91832e1619_img.jpg\) VARIABLE INTAKE-AIR SYSTEM STRUCTURE \[LF\]](#)
- [!\[\]\(3e91863309aa91e589b5ab92c8ebd53f_img.jpg\) VARIABLE INTAKE-AIR SYSTEM OPERATION \[LF\]](#)
- [!\[\]\(bf6def3f21dfdb4b0473718404626f2c_img.jpg\) VARIABLE TUMBLE SYSTEM FUNCTION \[LF\]](#)
- [!\[\]\(b0485233f98b941f2381b77fe3b6686f_img.jpg\) VARIABLE TUMBLE SYSTEM STRUCTURE \[LF\]](#)
- [!\[\]\(fd5c36680d4471e605732b36788643ca_img.jpg\) VARIABLE TUMBLE SYSTEM OPERATION \[LF\]](#)
- [!\[\]\(cfcb6e3fe14cf2366208370376c5c0f9_img.jpg\) VARIABLE INTAKE-AIR SOLENOID VALVE FUNCTION \[LF\]](#)
- [!\[\]\(17fbea93b96fb691279feb16b3dfba47_img.jpg\) VARIABLE INTAKE-AIR SOLENOID VALVE CONSTRUCTION/OPERATION \[LF\]](#)
- [!\[\]\(c943c40aac9d4dd9481d8d4b932db11b_img.jpg\) VARIABLE TUMBLE SOLENOID VALVE FUNCTION \[LF\]](#)
- [!\[\]\(78722dd8a40b4b8cba6c4bc2496af0ff_img.jpg\) VARIABLE TUMBLE SOLENOID VALVE CONSTRUCTION/OPERATION \[LF\]](#)
- [!\[\]\(7ca57550f01dd657cd5fb0b4b39070e5_img.jpg\) VARIABLE INTAKE-AIR SHUTTER VALVE ACTUATOR FUNCTION \[LF\]](#)
- [!\[\]\(27d08d42762e05345080235dfb8fd4f5_img.jpg\) VARIABLE INTAKE-AIR SHUTTER VALVE ACTUATOR CONSTRUCTION/OPERATION \[LF\]](#)
- [!\[\]\(a0120eed5345e3ef041f32d510bbaaa4_img.jpg\) VARIABLE TUMBLE SHUTTER VALVE ACTUATOR FUNCTION \[LF\]](#)
- [!\[\]\(5d135eaf0db5ba5bb50522e31d409887_img.jpg\) VARIABLE TUMBLE SHUTTER VALVE ACTUATOR CONSTRUCTION/OPERATION \[LF\]](#)