



Engine Control (1GD-FTV, 2GD-FTV)




Engine Control (1GD-FTV, 2GD-FTV)

*10 : w/ Air Fuel Ratio Sensor
*16 : w/ Urea Pump Control ECU




Engine Control (1GD-FTV, 2GD-FTV)

* 8 : Intelligent Manual Transmission
*16 : w/ Urea Pump Control ECU




Engine Control (1GD-FTV, 2GD-FTV)


* 6 : w/ A/C
* 8 : Intelligent Manual Transmission
* 16 : w/ Urea Pump Control ECU



Engine Control (1GD-FTV, 2GD-FTV)


Cruise Control (1GD-FTV, 2GD-FTV)






- * 8 : Intelligent Manual Transmission
- * 9 : w/ Combination Switch Assembly
- * 15 : w/ Stop & Start System
- * 16 : w/ Urea Pump Control ECU

ECT and A/T Indicator (1GD-FTV, 2GD-FTV)




ECT and A/T Indicator (1GD-FTV, 2GD-FTV)



ECT and A/T Indicator (1GD-FTV, 2GD-FTV)

*16 -w/ Urea Pump Control ECU



12 HILUX (Cont' d)

ECT and A/T Indicator (1GD-FTV, 2GD-FTV)

- * 1.: w/ TFT Display
- * 15.: w/ Stop & Start System
- * 16.: w/ Urea Pump Control ECU
- * 17.: w/ Stop & Start System

