

DTC 07:ER07

B3E090266900W22

DTC 07:Er07	MD player
DETECTION CONDITION	<p>Note</p> <ul style="list-style-type: none">• When error occurs, error message "CHECK MD" is displayed in the LCD.• Base unit detects MD reading error.
POSSIBLE CAUSE	<ul style="list-style-type: none">• Defective MD (scratches or dirt)• MD player malfunction

Diagnostic procedure

STEP	INSPECTION	ACTION
1	Verify the condition of the MD when the error occurs. Is the MD normal?	Yes Go to the next step.
		No Repair (remove foreign material, clean) or replace the MD, and go to the next step.
2	Clear the DTC, and then insert a normal MD. Play the MD for 12 s or more . Is DTC 07: Er07 displayed?	Yes Replace the MD player.
		No DTC troubleshooting completed.