

DTC TABLE [ZJ, Z6]

B3E010200102W22

×: Applicable
-: Not applicable

DTC No.	Condition	MIL	DC	Monitor item	Memory function	Page
P0011	CMP-timing over-advanced	ON	1	CCM	×	(See DTC P0011 [ZJ, Z6].)
P0012	CMP-timing over-retarded	ON	2	CCM	×	(See DTC P0012 [ZJ, Z6].)
P0031	Front HO2S heater control circuit low	ON	2	HO2S heater	×	(See DTC P0031 [ZJ, Z6].)
P0032	Front HO2S heater control circuit high	ON	2	HO2S heater	×	(See DTC P0032 [ZJ, Z6].)
P0037	Rear HO2S heater control circuit low	ON	2	HO2S heater	×	(See DTC P0037 [ZJ, Z6].)
P0038	Rear HO2S heater control circuit high	ON	2	HO2S heater	×	(See DTC P0038 [ZJ, Z6].)
P0102	MAF sensor circuit low input	ON	1	CCM	×	(See DTC P0102 [ZJ, Z6].)
P0103	MAF sensor circuit high input	ON	1	CCM	×	(See DTC P0103 [ZJ, Z6].)
P0111	IAT sensor circuit range/performance problem	ON	2	CCM	×	(See DTC P0111 [ZJ, Z6].)
P0112	IAT sensor circuit low input	ON	1	CCM	×	(See DTC P0112 [ZJ, Z6].)
P0113	IAT sensor circuit high input	ON	1	CCM	×	(See DTC P0113 [ZJ, Z6].)
P0117	ECT sensor circuit low input	ON	1	CCM	×	(See DTC P0117 [ZJ, Z6].)
P0118	ECT sensor circuit high input	ON	1	CCM	×	(See DTC P0118 [ZJ, Z6].)
P0121	TP sensor circuit range/performance problem	ON	2	CCM	×	(See DTC P0121 [ZJ, Z6].)
P0122	TP sensor circuit low input	ON	1	CCM	×	(See DTC P0122 [ZJ, Z6].)
P0123	TP sensor circuit high input	ON	1	CCM	×	(See DTC P0123 [ZJ, Z6].)
P0125	Insufficient coolant temperature for closed loop fuel control	ON	2	CCM	×	(See DTC P0125 [ZJ, Z6].)
P0132	Front HO2S circuit high voltage	ON	2	HO2S	×	(See DTC P0132 [ZJ, Z6].)
P0133	Front HO2S circuit slow response	ON	2	HO2S	×	(See DTC P0133 [ZJ, Z6].)
P0134	Front HO2S circuit no activity detected	ON	2	HO2S	×	(See DTC P0134 [ZJ, Z6].)
P0138	Rear HO2S circuit high voltage	ON	2	HO2S	×	(See DTC P0138 [ZJ, Z6].)
P0140	Rear HO2S circuit no activity detected	ON	2	HO2S	×	(See DTC P0140 [ZJ, Z6].)

P0300	Random misfire detected	Flash/ON	2	Misfire	×	(See DTC P0300 [ZJ, Z6].)
P0301	Cylinder No.1 misfire detected	Flash/ON	2	Misfire	×	(See DTC P0301, P0302, P0303, P0304 [ZJ, Z6].)
P0302	Cylinder No.2 misfire detected	Flash/ON	2	Misfire	×	(See DTC P0301, P0302, P0303, P0304 [ZJ, Z6].)
P0303	Cylinder No.3 misfire detected	Flash/ON	2	Misfire	×	(See DTC P0301, P0302, P0303, P0304 [ZJ, Z6].)
P0304	Cylinder No.4 misfire detected	Flash/ON	2	Misfire	×	(See DTC P0301, P0302, P0303, P0304 [ZJ, Z6].)
P0327	KS circuit low input	ON	1	CCM	×	(See DTC P0327 [ZJ, Z6].)
P0328	KS circuit high input	ON	1	CCM	×	(See DTC P0328 [ZJ, Z6].)
P0335	CKP sensor circuit problem	ON	1	CCM	×	(See DTC P0335 [ZJ, Z6].)
P0340	CMP sensor circuit problem	ON	1	CCM	×	(See DTC P0340 [ZJ, Z6].)
P0403	EGR control circuit problem	ON	2	CCM	×	(See DTC P0403 [ZJ, Z6].)
P0420	Catalyst system efficiency below threshold	ON	2	Catalyst	×	(See DTC P0420 [ZJ, Z6].)
P0443	Purge solenoid valve circuit problem	ON	2	CCM	×	(See DTC P0443 [ZJ, Z6].)
P0480	Cooling fan control circuit problem	OFF	1	Other	×	(See DTC P0480 [ZJ, Z6].)
P0500	VSS circuit problem	ON	2	CCM	×	(See DTC P0500 [ZJ, Z6].)
P0505	IAC system problem	OFF	-	-	-	(See DTC P0505 [ZJ, Z6].)
P0506	IAC system RPM lower than expected	ON	2	CCM	×	(See DTC P0506 [ZJ, Z6].)
P0507	IAC system RPM higher than expected	ON	2	CCM	×	(See DTC P0507 [ZJ, Z6].)
P0511	IAC circuit problem	ON	1	CCM	×	(See DTC P0511 [ZJ, Z6].)
P0550	PSP switch circuit problem	ON	2	CCM	×	(See DTC P0550 [ZJ, Z6].)
P0602	PCM programming error	ON	1	CCM	×	(See DTC P0602 [ZJ, Z6].)
P0610	PCM vehicle options error	ON	1	CCM	×	(See DTC P0610 [ZJ, Z6].)
P0660*1	Variable intake-air control circuit/open	OFF	1	Other	×	(See DTC P0660 [Z6].)
P0668	PCM temperature sensor circuit low input	OFF	1	Other	×	(See DTC P0668 [ZJ, Z6].)
P0669	PCM temperature sensor circuit high input	OFF	1	Other	×	(See DTC P0669 [ZJ, Z6].)
P0703	Brake switch input circuit problem	ON	2	CCM	×	(See DTC P0703 [ZJ, Z6].)

P0704	CPP switch input circuit problem	ON	2	CCM	×	(See DTC P0704 [ZJ, Z6].)
P0706	Transaxle range (TR) switch circuit range/performance	(See DTC TABLE [FN4A-EL].)				
P0707	Transaxle range (TR) switch circuit low input	(See DTC TABLE [FN4A-EL].)				
P0708	Transaxle range (TR) switch circuit high input	(See DTC TABLE [FN4A-EL].)				
P0711	Transaxle fluid temperature (TFT) sensor circuit range/performance (stuck)	(See DTC TABLE [FN4A-EL].)				
P0712	Transaxle fluid temperature (TFT) sensor circuit malfunction (short to ground)	(See DTC TABLE [FN4A-EL].)				
P0713	Transaxle fluid temperature (TFT) sensor circuit malfunction (open circuit)	(See DTC TABLE [FN4A-EL].)				
P0715	Input/turbine speed sensor circuit malfunction	(See DTC TABLE [FN4A-EL].)				
P0731	Gear 1 incorrect (incorrect gear ratio detected)	(See DTC TABLE [FN4A-EL].)				
P0732	Gear 2 incorrect (incorrect gear ratio detected)	(See DTC TABLE [FN4A-EL].)				
P0733	Gear 3 incorrect (incorrect gear ratio detected)	(See DTC TABLE [FN4A-EL].)				
P0734	Gear 4 incorrect (incorrect gear ratio detected)	(See DTC TABLE [FN4A-EL].)				
P0741	Torque converter clutch (TCC) (stuck off)	(See DTC TABLE [FN4A-EL].)				
P0742	Torque converter clutch (TCC) (stuck on)	(See DTC TABLE [FN4A-EL].)				
P0745	Pressure control solenoid malfunction	(See DTC TABLE [FN4A-EL].)				
P0751	Shift solenoid A stuck off	(See DTC TABLE [FN4A-EL].)				
P0752	Shift solenoid A stuck on	(See DTC TABLE [FN4A-EL].)				
P0753	Shift solenoid A malfunction (electrical)	(See DTC TABLE [FN4A-EL].)				
P0756	Shift solenoid B stuck off	(See DTC TABLE [FN4A-EL].)				
P0757	Shift solenoid B stuck on	(See DTC TABLE [FN4A-EL].)				
P0758	Shift solenoid B malfunction (electrical)	(See DTC TABLE [FN4A-EL].)				
P0761	Shift solenoid C stuck off	(See DTC TABLE [FN4A-EL].)				
P0762	Shift solenoid C stuck on	(See DTC TABLE [FN4A-EL].)				
P0763	Shift solenoid C malfunction (electrical)	(See DTC TABLE [FN4A-EL].)				
P0766	Shift solenoid D stuck off	(See DTC TABLE [FN4A-EL].)				
P0767	Shift solenoid D stuck on	(See DTC TABLE [FN4A-EL].)				
P0768	Shift solenoid D malfunction (electrical)	(See DTC TABLE [FN4A-EL].)				
P0771	Shift solenoid E stuck off	(See DTC TABLE [FN4A-EL].)				
P0772	Shift solenoid E stuck on	(See DTC TABLE [FN4A-EL].)				
P0773	Shift solenoid E malfunction (electrical)	(See DTC TABLE [FN4A-EL].)				

P0850	Neutral switch input circuit problem	ON	2	CCM	x	(See DTC P0850 [ZJ, Z6].)
P0894	Forward clutch torque transmission	(See DTC TABLE [FN4A-EL].)				
P1260	Immobilizer system problem	OFF	-	Other	-	(See DTC P1260 [ZJ, Z6].)
P2006	Variable tumble control stuck close	ON	2	CCM	x	(See DTC P2006 [ZJ, Z6].)
P2008	Variable tumble control circuit/open	ON	2	CCM	x	(See DTC P2008 [ZJ, Z6].)
P2088	Variable valve timing control circuit low	ON	1	CCM	x	(See DTC P2088 [ZJ, Z6].)
P2089	Variable valve timing control circuit high	ON	1	CCM	x	(See DTC P2089 [ZJ, Z6].)
P2096	Target A/F feedback system too lean	ON	2	Fuel system	x	(See DTC P2096 [ZJ, Z6].)
P2097	Target A/F feedback system too rich	ON	2	Fuel system	x	(See DTC P2097 [ZJ, Z6].)
P2177	System too lean off idle	ON	2	Fuel system	x	(See DTC P2177 [ZJ, Z6].)
P2178	System too rich off idle	ON	2	Fuel system	x	(See DTC P2178 [ZJ, Z6].)
P2187	System too lean at idle	ON	2	Fuel system	x	(See DTC P2187 [ZJ, Z6].)
P2188	System too rich at idle	ON	2	Fuel system	x	(See DTC P2188 [ZJ, Z6].)
P2195	Front HO2S signal stuck lean	ON	2	HO2S	x	(See DTC P2195 [ZJ, Z6].)
P2196	Front HO2S signal stuck rich	ON	2	HO2S	x	(See DTC P2196 [ZJ, Z6].)
P2228	BARO sensor circuit low input	ON	1	CCM	x	(See DTC P2228 [ZJ, Z6].)
P2229	BARO sensor circuit high input	ON	1	CCM	x	(See DTC P2229 [ZJ, Z6].)
P2502	Charging system voltage problem	OFF	1	-	-	(See DTC P2502 [ZJ, Z6].)
P2503	Charging system voltage low	OFF	1	-	-	(See DTC P2503 [ZJ, Z6].)
P2504	Charging system voltage high	OFF	1	-	-	(See DTC P2504 [ZJ, Z6].)
P2507	PCM power input signal low	ON	1	CCM	x	(See DTC P2507 [ZJ, Z6].)
U0073	Control module communication bus off	(See DTC TABLE [MULTIPLEX COMMUNICATION SYSTEM].)				
U0121	Lost communication with anti-lock brake system (ABS) control module	(See DTC TABLE [MULTIPLEX COMMUNICATION SYSTEM].)				
U0155	Lost communication with instrument panel cluster (IPC) control module	(See DTC TABLE [MULTIPLEX COMMUNICATION SYSTEM].)				

*1 : Z6