

DTC P1260 [LF]

B3E010201200W01

DTC P1260	Immobilizer system problem
DETECTION CONDITION	<ul style="list-style-type: none"> The instrument cluster detects an immobilizer system malfunction. Diagnostic support note <ul style="list-style-type: none"> This is a continuous monitor (Other). The MIL does not illuminate. PENDING CODE is available if the PCM detects the above malfunction condition. FREEZE FRAME DATA is available. The DTC is not stored in the PCM memory.
POSSIBLE CAUSE	<ul style="list-style-type: none"> Immobilizer system malfunction PCM malfunction

Diagnostic procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has FREEZE FRAME DATA been recorded? 	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA on the repair order, then go to the next step.
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related service repair information availability. Is any related repair information available? 	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	VERIFY STORED DTC IN INSTRUMENT CLUSTER <ul style="list-style-type: none"> Turn the ignition switch to the ON position (Engine off). Verify stored DTCs in instrument cluster. (See DTC INSPECTION [IMMOBILIZER SYSTEM].) Are DTCs stored? 	Yes	Go to the appropriate DTC inspection. (See DTC TABLE [IMMOBILIZER SYSTEM] .)
		No	Go to the next step.
4	VERIFY TROUBLESHOOTING OF DTC P1260 COMPLETED <ul style="list-style-type: none"> Make sure to reconnect all disconnected connectors. Clear the DTC from the PCM memory using the WDS or equivalent. Start the engine. Is the same DTC present? 	Yes	Replace the PCM, then go to the next step. (See PCM REMOVAL/INSTALLATION [LF] .)
		No	Go to the next step.
5	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [LF].) Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [LF] .)
		No	DTC troubleshooting completed.